




# TOP AND CONSOLE PARTS

For Models: LER7646DW0, LER7646DQ0, LER7646DZ0  
(White) (Designer White) (Designer Almond)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Models: LER7646DW0, LER7646DQ0, LER7646DZ0  
(White) (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console	12	339229	Hinge, R.H.	25	3401684	Wire, Jumper (Black)
2	688805	Clip		339230	Hinge, L.H.	30	357213	Nut, Push-In (2)
3	3396029	Wire-Jumper Assembly	13	688983	Screw, 8-18 x 5/8	31	3401631	Harness, Wiring (Includes 690261 Terminal Block)
4		Cap, End (L.H.) (MODEL)	14	693995	Screw, Hex Head Top	32	3390646	Screw, 8-18 x 5/16
	3358531	LER7646DW0	16	3396022	White	39	3398095	Relay, Push-To-Start
	3358528	LER7646DQ0		3396023	Almond	48		Timer Knob Assembly (MODEL)
	3358529	LER7646DZ0	17	694419	Buzzer, Mini		3396145	LER7646DW0
5	3390647	Screw, 8-18 x 1/2	18		Knob, Control (MODEL)		3396146	LER7646DQ0
6	3353145	Screw, Console		3358431	LER7646DW0		3396149	LER7646DZ0
7	689180	Clip, Retainer		3358435	LER7646DQ0	53	3396293	Bracket, Control Panel, Control (MODEL)
8		Cap, End (R.H.) (MODEL)		3358436	LER7646DZ0	54		LER7646DW0
	3358516	LER7646DW0	19	3347243	Connector-6 Circuit		3399032	LER7646DQ0
	3358513	LER7646DQ0	20	3395683	Connector, Housing		3399033	LER7646DZ0
	3358514	LER7646DZ0	21	3398137	Timer, 60 Hz.		3399034	Wire, Ground
9	3388706	Resistor, Timer	22	3401144	Connector (Relay/Buzzer)	72	690853	Switch, Cycle Selection
10	349639	Screen, Lint	23	3394427	Clip, Harness	79	3396013	
11		Cover, Lint Screen	24	3397269	Connector, Timer			
	688150	White						
	689310	Almond						


## LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>LITERATURE PARTS</b>			<b>OPTIONAL PARTS NOT INCLUDED</b>					
	LIT3401092	Guide, Use & Care	<b>PAINT, TOUCH-UP (1/2oz.)</b>			<b>PAINT, BULK (1 qt.)</b>		
	LIT3397597	Instructions, Installation		72017	White		799344	White (Uncut)
	LIT3401723	Label, Wiring Diagram		72107	Almond		978883	Almond (Uncut)
<b>Following May Be Purchased</b>			<b>PAINT, PRESSURIZED SPRAY (13 oz.)</b>					
<b>DO-IT-YOURSELF REPAIR MANUALS</b>				350930	White			
	LIT677818	Dryer		350956	Almond			
				350938	Primer, Gray			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: LER7646DW0, LER7646DQ0, LER7646DZ0  
(White) (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: LER7646DW0, LER7646DQ0, LER7646DZ0  
(White) (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	3393008	Screw, 10-16 x 1/2	18		Cabinet	37		Handle, Door
4	237979	Spring, Door (2)		3399585	White		690270	White
5	3396795	Cover, Terminal Block		3399586	Almond		690271	Almond
6	694091	Screw			(Includes Illus. Nos. 5, 7, 16, 41 and 57)	38	349464	Seal & Bearing Assembly
7	3396805	Panel, Rear	19	98234	Clip, Ground	40	279393	Terminal Block Kit For
8	3388229	Clip, Toe Panel (2)	20	690363	Lock, Front Top (2)			Terminal Block
9	3357011	Screw, 10-16 x 1/2	21		Upper Front Panel	41	690261	Block, Terminal
10	347207	Switch, Door		338012	White	51	238088	Hinge, Top (2)
11	98129	Screw, 6-20 x 1-3/8 (2)		689533	Almond	53	691366	Idler & Pulley Assembly
12	691581	Lever, Door Switch	22		Panel, Toe	56	660996	Belt, Drive
13	693995	Screw, Rear Panel Mounting		692427	White	57	348780	Base, Motor
14	687905	Hinge, R.H.		692428	Almond	58	172455	Bolt, 5/16-18 x 3/4
	687906	Hinge, L.H.	23	685203	Clip, Felt Pad	59	3401143	Pulley, 60 Hz.
15	343641	Screw, 10-16 x 1/2	24	337189	Clip, Hinge (2)	62	3395652	Motor Assembly 60 Hz.
16	3392100	Foot, Dryer	28	238614	Bumper	63	660658	Clamp, Motor 343481 (Alt.)
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	29	297092	Clip, Hinge (2)			685441 (Alt.)
			30	690081	Catch, Door	67	3390733	Seal, Door
			33	696144	Strike, Door	87	697776	Screw, 10-32 x 1/2 (External Ground)
			35	695954	Door, Rear			Terminal, Tinned & Brass (3) (Includes Illus. 40)
17	342043	Screw, 10-32 x 1/2	36		Door Front	90	279318	
				348728	White			
				689330	Almond			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: LER7646DW0, LER7646DQ0, LER7646DZ0  
(White) (Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	3396352	Lint Chute Assembly
2	3400800	Screw, 8-18 x 3/4
3	359702	Cap, Screw
5	90767	Screw, 8 x 3/8
6	3399848	Thermal, Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)
7	347139	Seal, Lint Chute
8	3388703	Washer, Support
10	694089	Wheel, Blower
11	695081	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2

Illus. No.	Part No.	DESCRIPTION
14	3397566	Box, Heater
15	3390291	Thermostat, High Limit 250°F (121.1°C) (60 Hz.)
17	3398064	Element, Heater (For 240 Volt Installation)
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
22	3392123	Seal, Blower
23	3392519	Fuse, Thermal
24	3387139	Thermostat, Internal Bias

Illus. No.	Part No.	DESCRIPTION
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3399464	Bulkhead
62	3394509	Ring, Bearing
63	97787	Screw, 11-16 x 7/8
66	3397509	Seal, Rear Drum
67	3396778	Drum Assembly
68	342847	Baffle, Drum
69	3394133	Bracket, Support
70	90296	Clip
73	3398160	Seal
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST